



Now, get the most out of your Henrob rivet gun!
Convert your Henrob riveter into a complete Pro Spot Rivet solution.

With Pro Spot's Conversion kit, you're now able to Remove and Apply Self Piercing Rivets (SPR), reach into those 'hard to access' spots on the Ford F series. Add in the optional Blind Rivet Adapter and safely install Blind Rivets.

The Henrob conversion kit comes with everything you need to safely convert your Henrob rivet gun to the Pro Spot rivet system.



Use the Blind Rivet Adapter with the Henrob Conversion Kit

OPTIONAL ACCESSORIES



Blind Rivet Adapter
PR-PA-20



120mm Extension Arm
PRR-CQ-120-80



Tesla Die Kit
SA-9018: Die Kit

Note: View all instructional materials (video and written instructions) before proceeding with the conversion.
Warning! High pressure spring can cause injury so be sure to follow all instructions provided!

